



GutterFlow Installation



REMEMBER

ALWAYS leave a gap between the gutter and the stop ridge




Fundi Maalum

GutterFlow Storage



Lay gutters on a smooth, flat surface



DO NOT store in direct sunlight



DO NOT stack gutters above 1.25m



Store in a well-ventilated, cool space whilst wrapped. Direct sunlight or hot unventilated places can cause the temperature of materials to rise in extreme conditions can result in distortion.

